

# NEGARA BRUNEI DARUSSALAM

AIRAC  
AIP SUPPLEMENT

TEL : 673-2331730  
AFS : WBSBYNYX  
FAX : 673-2331706  
673-2331730  
E-mail:[ais.brunei@civil-aviation.gov.bn](mailto:ais.brunei@civil-aviation.gov.bn)  
Website: [www.civil-aviation.gov.bn](http://www.civil-aviation.gov.bn)

AERONAUTICAL INFORMATION SERVICE  
DEPARTMENT OF CIVIL AVIATION  
MINISTRY OF TRANSPORT AND  
INFOCOMMUNICATIONS  
BRUNEI INTERNATIONAL AIRPORT, BB2513

19/19  
19<sup>th</sup> Dec

## **ESTABLISHMENT OF CONTROL ZONE AND SPECIAL RULES AREA - ANDUKI AERODROME -**

### **1. INTRODUCTION**

- 1.1 The purpose of this AIP Supplement is to notify the aviation industry of the establishment of Anduki Control Zone and Special Rules Area (WBAK)

### **2. DETAILS OF CONTROL ZONE AND SPECIAL RULES AREA INCLUDING THE CHARTS**

- 2.1 See Attachment overleaf for details and description WBSB AD2.17 and chart of Anduki Control Zone (CTZ) and Special Rules Area (SRA).

### **3. IMPLEMENTATION**

- 3.1 This AIP Supplement will become effective on 30 January 2020.

### **4. CANCELLATION**

- 4.1 This AIP Supplement will remain current until the information is published in AIP Brunei

**WBAK AD 2.17 ATS AIRSPACE**

1	Designation and lateral limits	<p>Anduki CTZ is defined as a rectangular area roughly centered at Anduki Aerodrome Reference Point (043815N 1142256E). The area starts from point A 9NM West of Anduki Airfield at WGS 84 Coordinate (043807N 1141356E), thence straight line to Point B (044606N 1142716E) thence a straight line to Point C (044024N 1143111E) thence straight line to Point D (043131N 1141830E) and a straight line terminated at Point A.</p> <p>Anduki Special Rules Area (SRA) are defined as area from Anduki CTZ point 043558N 1141524E thence along the coast to the west 043514N 1140701E thence straight line to the north 050557N 1140323E thence straight line to join an arc of Circle 5NM radius centred on 051237N 1144452E from 051157N 1143854E clockwise to 051334N 1144829E clockwise to 050640N 1144232E thence straight line to 045839N 1143709E thence straight line to 044403N 1143342E thence along the coast joining the Control Zone point 044150N 1143012E thence straight line to Point B(044606N 1142716E) thence straight line to point A(043807N 1141356E) thence straight line joining point 043558N 1141524E</p>
2	Vertical limits	CTZ - 2000ft GND Level SRA - 2000ft GND / Sea Level
3	Airspace classification	Class C and D
4	ATS unit call sign Language(s)	Anduki Tower, English
5	Transition altitude	11,000 ft
6	Remarks	Nil

**Ridzuan Haji Ahmad**  
**Acting Director of Civil Aviation**  
**Department of Civil Aviation**  
**Brunei Darussalam**

## CONTROL ZONE(CTZ) AND SPECIAL RULES AREA(SRA)

### -ANDUKI-

